



## Technical data

	Substance
Backing	elastic PE film
Adhesive	Acrylate contact adhesive
Release film	siliconized paper

Attribute	Regulation	Value
Colour		white / blue
Exposure time		6 months
Application temperature		above -10 °C ; 14 °F
Temperature resistance		permanent -40 °C to 90 °C ; -40 °F to 194 °F
Storage		cool and dry

## Area of application

COMPEGO is used to bond overlaps between vapour check and airtightness membrane securely, air tightly and permanently as well as for indoor and exterior joints between such membranes. Also suitable for bonding butt joints between woodbased panels.

## Forms of delivery

Art. no.	GTIN	Length	Width	Weight	Sales unit	Container
15357	4026639153579	25 m	60 mm	7 kg	1	60
15385	4026639153852	25 m	100 mm	11.7 kg	1	60
15386	4026639153869	25 m	150 mm	17.5 kg	1	60

## Advantages

- ✓ 6 months of outdoor exposure
- ✓ With elastic backing film, can be torn off by hand
- ✓ For airtight bonds according to DIN 4108-7, SIA 180 and RT 2012
- ✓ Waterproof adhesive
- ✓ Excellent values in the hazardous substance test, has been tested according to the ISO 16000 evaluation scheme

# MOLL

## Substrates

Clean subsurfaces before sticking.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all vapour retarder and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other underlay/sarking and wall lining membranes (e.g. those made of PP and PET).

Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood fibre underlay panels).

Wood fibre sub-roof panels and smooth mineral subsurfaces require pre-treatment with TESCON PRIMER before bonding. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

## General conditions

The bonds should not be subjected to tensile strain.

Once membranes have been stuck, the weight of the insulation material must be supported by laths.

Adhesion should be supported by additional laths, if necessary.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof bonding can only be achieved on vapour retarders or underlay/sarking/facade membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

## Ecological Building Systems

For stockist information and full technical support for your project, please contact Ecological Building Systems or visit [www.EcologicalBuildingSystems.com](http://www.EcologicalBuildingSystems.com)



Ireland: 046 9432104 Fax: 046 9432435 UK: 01228 711 511 Fax: 01228 712 280

[info@EcologicalBuildingSystems.com](mailto:info@EcologicalBuildingSystems.com)