

Installation instructions INSTAABOX

Installation steps



1. Create the cut-out

Mark out the position of the INSTAABOX and create the cut-out in the airtightness layer.

Dimensions 270 mm x 140 mm.

It can be installed either vertically or horizontally.



2. Pre-form the penetrations

Punch holes at the perforated punching points on the INSTAABOX using a conical object (e.g. a nail or cartridge nozzle).

Create a hole that is about 60% of the cable diameter.



3. Feed the cables through

Support the INSTAABOX with your hand at the penetration point and pull cables with a diameter of up to 20 mm through the previously created holes.

The plastic will create an airtight seal.

Ensure that cables sit freely and are not subject to tension in the INSTAABOX.



4. Put the INSTAABOX in place

Align the box with pulled-through cables on the airtightness layer.



5. Create an airtight bond

Create an airtight bond around the perimeter of the box using a pro clima adhesive tape (e.g. TESCON VANA) and rub firmly in place (PRESSFIX).

Ensure that there is sufficient resistance pressure.



6. Can be expanded flexibly

The installed INSTAABOX has enough space for up to three sockets or light switches.

Combine two or more boxes if greater lengths or widths are required.

Substrates

The INSTAABOX can be used on all common airtight substrates used in construction. Recommendations on suitable sealants for connecting it to the airtight sealing layer (e.g. vapour retarder, wood-based panels or mineral substrate) is given in the pro clima application matrix [<https://proclima.com/media-download/350/>].

Further information can be found in the technical data sheets provided with the sealant.

General conditions

The bonds should not be subjected to tensile strain.

When the vapour control membrane is sealed, the weight of the insulating material must be borne by lathing. Adhesion should be supported by additional laths, if necessary.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure.

Airtight seals can only be achieved on vapour control membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about application and construction is given in the pro clima planning documentation and application recommendations. If you have any questions, please call the pro clima technical hotline Ireland and UK:

Phone: +353 46 9432104

Fax: +353 46 9432435

info@ecologicalbuildingsystems.com

For Stockists contact

Ireland

Phone: +353 (0)46 9432104

Fax: +353 (0)46 9432435

UK

Phone: +44 (0)1228 711 511

Fax: +44 (0)1228 712 280

Ecological Building Systems

info@ecologicalbuildingsystems.com

www.ecologicalbuildingsystems.com

MOLL bauökologische Produkte GmbH

Rheintalstraße 35 - 43

68723 Schwetzingen

Germany

www.proclima.com